



CrashGuard™ drum mic shield

USER GUIDE



The CrashGuard is made from 75% recycled materials.



Congratulations on your purchase of the CrashGuard! This handy device will help improve your mixes by giving you greater control over the sound of the snare and toms with less bleed from the cymbals.

The CrashGuard is extremely simple to use. It is designed to fit any standard boom arm or gooseneck. Begin by taking the mic clip off your mic stand boom arm. Make sure you leave the knurled ring on that usually comes with most booms. The CrashGuard comes equipped with a spare ring in case you do not have one. Push the CrashGuard onto the mic stand boom arm, holding the CrashGuard in place with one hand. Then, take the mic clip and screw it onto the boom. Do not over tighten. Rotate the CrashGuard so that the microphone clip is pointing in the right direction and then slide the mic into the clip. You can now connect the mic by passing it through the rear access port. Snug the mic clip and boom so that everything is secure.

The CrashGuard is designed to fit most microphones and allows the mic to be adjusted forward and backward plus be articulated up and down. Because most drum mics are cardioid, try to leave some space between the mic head (capsule) and the inside top of the CrashGuard. This will reduce any effect the shell may have on the mic's polar pattern.

You are now ready to beat the drum loudly!

LIMITED WARRANTY

Primacoustic products are guaranteed to be free of manufacturing defects for a period of thirty (30) days after purchase. In the unlikely event that a defect is uncovered, please email info@primacoustic.com or call 604-942-1001 to obtain a return authorization number (RA#) from Primacoustic before the thirty (30) day warranty period expires. Once you have obtained an RA number return the product, freight prepaid, within fifteen (15) days after the date the RA number is issued. In the original packaging (or another, affording an equal degree of protection) with all of the following: (1) RA number clearly marked on the returned package; (2) a copy of the original bill of sale showing proof of purchase from an authorized retail seller; and (3) a written note describing the defect including your name, address, telephone number, email address and the applicable RA number. You are solely responsible for all shipping and insurance costs for returning the product to Primacoustic, and you will not be reimbursed or compensated for any loss or damage incurred. Primacoustic will at its discretion repair or replace the product. Should the product be no longer available, Primacoustic reserves the right to exchange this with a product of similar performance and value. Due to different dye lots, Primacoustic cannot guarantee exact color match. This Warranty shall solely extend to the original owner and is limited to manufacturing defects only and excludes damage due to improper installation, freight handling, wear and tear, abuse, misuse, misapplication, color fading or deterioration due to prolonged exposure to ultra violet light, smoke, humidity or other environmental factors. It is understood that the use and suitability of the product is entirely the responsibility of the buyer or specifying engineer and as such, these parties agree to hold Primacoustic, or its associated company, and/or officers, harmless from any responsibility whatsoever other than what is clearly outlined in this warranty. This warranty gives you specific legal rights, and you may also have other rights, which may vary depending on where you live and where the product was purchased.



1588 Kebet Way, Port Coquitlam, BC, Canada, V3C 5M5
Tel: 604-942-1001 • Fax: 604-942-1010 • info@primacoustic.com

Primacoustic is a division of Radial Engineering Ltd.
CrashGuard User Guide #R870 2059 00. Specifications
and appearance subject to change without notice.
Copyright 2010, all rights reserved.

www.primacoustic.com