

BT-U3

Testeur de pile 1,5V, 3V et 3,7V JJC Battery Tester BT-U3

Tension	Compatibilité	Signal
1.5 V	LR44, LR41, LR43, LR44H, A76 AA , AAA, C, D	No Lights On: <0.84V
		1 Light On: 0.84-1.13V
		2 Lights On: 1.13-1.33V
		3 Lights On: > 1.33V
3 V	CR2032, CR2025, CR1632, CR2450, CR1225, CR1616 CR123A, CR2, CR123, CR1/3N	No Lights On: <2.55V
		1 Light On: 2.55-2.7V
		2 Lights On: 2.7-2.85V
		3 Lights On: >2.85V
3.7 V	18650, 14500, 16340, 10440, 20700, 26650, RCR123A	No Lights On: <3.30V
		1 Light On: 3.30-3.7V
		2 Lights On: 3.70-3.95V
		3 Lights On: >3.95V

