



MTP 5 / MTP 5 SWITCH

First steps

Connect your microphone with an audio interface, mixer, or preamp using a 3-pin XLR cable.

Check the on/off switch (MTP 5 switch only).

Set the input gain on your preamp

Rock!

Please note

- To ensure the best sound quality, do not cover any part of the grille.
- Avoid excessive force on switches and connected cables.
- Do not attempt to modify or fix the microphone, as it would void your product warranty.
- The microphone's housing can be cleaned easily using a wet cloth.
- The integrated acoustic pop and windshield can be washed with soap water, if necessary.

Tips and tricks

For best performance and level, point the mic directly at your mouth at a distance of 5 to 10 cm.

Do not cover the grille, as it would drastically change the sound and behavior of the microphone.

Do not point the mic towards a speaker while monitoring to avoid feedback.

In windy conditions, use the windscreen.

Specifications

Type	Dynamic, moving coil
Acoustical operating principle	Pressure gradient transducer
Polar pattern	Cardioid
Sensitivity	2 mV/Pa, -54 dBV/Pa
Internal impedance	280 Ω
Connector	Gold plated 3-pin XLR
Microphone net weight	336 g, 11.9 oz
Microphone dimensions	48 dia. x 179 mm, 1.9 dia. x 7 in
Microphone enclosure	Zinc die cast